



Additional Benefits

Rental Coverage

If your vehicle is required to be in a repair facility overnight for covered repairs, then we will reimburse you for car rental costs incurred - up to 6 days.

Towing

When towing is necessary, your vehicle will be towed to the closest licensed service facility or to any other location requested (up to 15 miles).

Flat Tire Assistance

Service consists of the removal of the flat tire and its replacement with your good spare tire.

Fuel, Oil, Fluids Delivery Service

An emergency supply of fuel, oil, fluid and water will be delivered if you are in immediate need. You must pay for the fuel or other fluid when it is delivered.

Lock-Out Assistance

If your keys are locked inside the vehicle, assistance will be provided to gain entry into the vehicle.

Battery Assistance

If battery failure occurs, a jump start will be provided to start your vehicle



P.O. Box 457 Mahwah, NJ 07430

888-361-9611

dealerloyaltyprotection.com



To File A Claim:
visit dealerloyaltyprotection.com

or

Call: 844-241-5518

Email: claims@dealerloyaltyprotection.com

In Florida, products and services are provided by Lyndon Southern Insurance Company (FL: Lic. No.: FL-03698). This is a summary of the benefits available. For complete information including details of benefits, coverage, specific exclusions, conditions, and limitations please refer to the complete terms and conditions of the service contract. A service contract is optional, cancellable and in no way required to obtain credit. A service contract is not a warranty.

Peace of Mind. Certified.



IntelliDrive

Vehicle Service Contract



IntelliDrive

Vehicle Service Contract

Coverage Levels:

POWERTRAIN PLUS COVERAGE: GOOD

Gasoline Engine: All internal lubricated parts including pistons, piston rings and pins, crankshaft and main bearings, connecting rods and rod bearings, camshaft and bearings, pushrods, rocker arm and followers, timing belt/chain and gears, valves, valve springs, seats and guides, lifters, oil pump, manifolds, flywheel, ring gear, flex plate, core plugs, harmonic balancer and bolt, valve covers, timing cover, oil pan, vacuum pump, engine mounts. Also covered are turbocharger/supercharger housing, all internal parts, and the waste gate. The engine block and cylinder head are covered only if damaged by an internal lubricated part.

Transmission: All internal lubricated parts in the transmission case including bands, clutch packs, gears, pumps, shafts, shift forks, shift rails, synchronizers, and solenoids. The torque converter, bell housing, vacuum modulator, transmission mounts, and transmission pan. The transmission case is covered only if it is damaged by an internal lubricated part.

Transfer Case: All Internally lubricated parts contained within the Transfer Case. The Transfer Case is also covered if damage is the result of the failure of an Internal Part of the Transfer Case.

Drive Axle: 2WD / 4WD / ALL-WHEEL: All internal lubricated parts in the drive axle, axle shafts, differential cover, universal joints and yokes, constant velocity and double offset joints, wheel bearings, drive shaft, drive shaft center bearing, locking hub mechanism. The drive axle housing is covered only if damaged by an internal lubricated part.

Seals and gaskets: Should seals and gaskets be required in conjunction with the repair of a covered component, coverage will be extended to include seals and gaskets on said covered components up to 100,000 miles. Cylinder head gasket(s) and intake manifold gaskets are the only gaskets covered as a gasket failure ALONE.



DLP is a national provider of protection products and has 1st Class customer and claims service.

Air Conditioning: Expansion valve, pressure cutoff switches, orifice tube and dryer, Condenser, Compressor, Evaporator, Lines and Fittings, Internal assembly including pistons, rods, valves, bearings and shafts, clutch and pulley. NOTE: O.E.M. refrigerants are to be used if replacement is required. If failure is due to a covered component, and fluid conversion is necessary, the Contract will cover the conversion parts and labor only. For hoses, O-rings seals, refrigerants and other non-covered components the contract holder is responsible.

Steering: Power steering fluid cooler, steering column coupling, power steering pump, steering main and intermediate shafts, power cylinder assembly, Pitman arm, idler arm, tie rods link, power steering cooler, power steering control valve and cylinder, steering box or rack.

Brakes: Master cylinder, power assist boosters and valves, wheel cylinders and calipers, combination valve, steel lines and fittings, backing plates, power brakes cylinder, vacuum assist booster pump, springs, clips and retainer, self-adjusters, rear activators, parking brake linkage and cables.

Fuel System: Fuel pump, metal fuel lines, fuel injectors, diesel fuel injection pump, diesel injectors, diesel vacuum pump.

Cooling System: Water pump. Radiator and heater core only if leaking.

Base Electrical: Alternator, starter motor and solenoid, distributor, ignition coil, ignition module.

STATED COMPONENT COVERAGE: BETTER

(INCLUDES POWERTRAIN PLUS COVERAGE PLUS BELOW)

Suspension: Upper and lower control arms, control arm shafts and bushings, upper and lower ball joints, front wheel drive hub and bearing assembly, steering knuckles, stabilizer shaft and bushings, king pins and bushings, strut bar and bushings, spindles and spindle supports, and wheel bearings.

High Tech Electrical: Cruise control servo/transducer, factory compass, factory thermometer, headlight switch, horn, ignition lock cylinder, ignition switch, power antenna, power lock actuators, windshield wiper motor, windshield wiper module, windshield washer pump, power window motors and power window regulator. Electronic speedometer display and module, engine control module, power sun/moon roof motor, power convertible top electric motor, crank sensor, knock sensor, oil temp sensor, camshaft positioning sensor, mass air flow sensor, BAP sensor MAP sensor, upstream oxygen sensors, downstream oxygen sensors, heated oxygen sensors, throttle positioning sensor engine coolant temperature sensor, intake air temperature sensor, neutral or park position sensor, brake fluid pressure sensor, PFE sensor, pressure sensors.

Anti-Lock Brakes: Booster and pump, master cylinder, control processor and solenoids.

EXCLUSIONARY COVERAGE: BEST!

This coverage is so extensive it covers virtually all mechanical and electrical components except for those listed in the "Exclusions" Section of the service contract. Examples of Excluded items are glass, batteries, tires, light bulbs, brakes, maintenance, and trim or moldings.

* Refer to your contract for details, conditions, terms and exclusions.



Peace of Mind.

Certified.